

Panic Button



By adding a panic button to your system, your security alarm can protect you and your family when you're home, whether or not your system is armed! When hit, the panic alarm will sound the siren, unless you in your system and alert the authorities of an emergency situation.

A panic button can be placed anywhere in your home. A suggested location is in your bedroom, next to the bed on your nightstand or mounted on the wall. If you hear someone at night, you can quickly sound the alarm!

If you own a business, use a panic button with your system to keep your employees safe. A panic button works great under a store counter, receptionist desk, or in a room where you keep valuables! Many professionals, such as therapists, teachers and HR representatives, keep a panic button under their desks as well, as extra protection for when they are in a one-on-one situation.

Panic buttons are great components to have with your system. By placing them around your house, you'll protect yourself, your family and your employees whether its day or night. Keep in mind, too, your key chain remote has a panic button and so does your keypad!

Forest's personal panic button can be worn as a pendant, watch or mounted on a wheel chair.

